



To install a new lock in you 1000 Series Lateral File:

1. Remove the old parts except the Lock Wire.
2. Slide the eyelet of the Lock Wire over the Short End of the Cam Wire as shown.
3. Slide the Bracket over the Long End of the Cam Wire.
4. Insert the Short End of the Cam Wire into the hole in the Vertical Rail Attachment.
5. Insert the Lock through the hole in the Top Panel, and through the Bracket. Make sure the post on the lock is underneath the Cam Wire.
6. Slide the Retainer Clip into the grooves on the Lock as far as it will go. (It will take some force to install the Retainer Clip. Avoid sheet metal edges which may be sharp).